

TENDICATENA PER MOTOSEGHE CHAIN TIGHTNERS FOR CHAINSAWS

Art. 54.270.3003
 Tendicatena adattabile a
 Chain tightner fits

ALPINA

CX 40 • 330 • 380 • 432 • 438



10 pezzi/pieces

Art. 54.270.3004
 Tendicatena adattabile a
 Chain tightner fits

COMER

E21ELETTROSEGA
 ELECTRIC SAW



10 pezzi/pieces

Art. 54.270.3009
 Tendicatena adattabile a
 Chain tightner fits

DOLMAR

133 SUPER • 143
 Filetto (Thread) M 6 x 70
 (2° serie - 2nd series)



10 pezzi/pieces

Art. 54.270.3014
 Tendicatena adattabile a
 Chain tightner fits

DOLMAR

133 • 133 SUPER • 143
 Filetto (Thread) M 6 x 60
 (1° serie - 1st series)



10 pezzi/pieces

Art. 54.270.3011
 Tendicatena adattabile a
 Chain tightner fits

DOLMAR

• 103 • 105 • 108 •



10 pezzi/pieces

Art. 54.270.3012
 Tendicatena adattabile a
 Chain tightner fits

DOLMAR

• 112 • 113 • 114 • 116
 • 117 • 119 • 120 •



10 pezzi/pieces

Art. 54.270.3010
 Tendicatena adattabile a
 Chain tightner fits

DOLMAR

116SI • 120 SI Filetto M 6 x 65



10 pezzi/pieces

Art. 54.270.3015
 Tendicatena adattabile a
 Chain tightner fits

DOLMAR

109 • 110 • 111 • 115 •



10 pezzi/pieces

Art. 54.270.3021
 Tendicatena adattabile a
 Chain tightner fits

ECHO

• 302 • 315 •



10 pezzi/pieces

Art. 54.270.3022
 Tendicatena adattabile a
 Chain tightner fits

ECHO

451 • 452 • 601 • 602 • 701 • 702



10 pezzi/pieces

Art. 54.270.3023
 Tendicatena adattabile a
 Chain tightner fits

ECHO

• CS 60S • CS 100 S



10 pezzi/pieces

Art. 54.270.3006
 Tendicatena adattabile a
 Chain tightner fits

ECHO

• 440 • 500 • 510 • 550 • 600 • 610
 • 650 • 750



10 pezzi/pieces

Art. 54.270.3005
 Tendicatena adattabile a
 Chain tightner fits

HOMELITE

XL • XL2 •
 Super 2 •
 VI Super 2 •
 240 • 245 •



10 pezzi/pieces

Art. 54.270.3052
 TENDICATENA adattabile a
 Chain tightner fits

HOPERM

15 • 165



10 pezzi/pieces

Art. 54.270.3039
 TENDICATENA adattabile a
 Chain tightner fits

HUSQVARNA

• 50 • 51 • 55 • 234 • 238 • 242
 • 244 • 246 • 340 • 444



10 pezzi/pieces

Art. 54.270.3054
 TENDICATENA adattabile a
 Chain tightner fits

HUSQVARNA

• 362 • 365 • 372 • 385 •



10 pezzi/pieces

Art. 54.270.3018
 TENDICATENA adattabile a
 Chain tightner fits

HUSQVARNA

• 345 •



10 pezzi/pieces

Art. 54.270.3032
 Tendicatena adattabile a
 Chain tightner fits

HUSQVARNA

65 • 77 • 180 • 280 • 380 •



10 pezzi/pieces

Art. 54.270.3033
 Tendicatena adattabile a
 Chain tightner fits

HUSQVARNA

61 • 181 • 266 •
 1° SERIE (1st series)



10 pezzi/pieces

Art. 54.270.3037
 Tendicatena adattabile a
 Chain tightner fits

HUSQVARNA

• 61 • 66 • 162 • 181 • 266
 • 268 • 272 • 281 • 288

JONSERED

• 626 • 630 • 670 • 2° serie (2nd series)



10 pezzi/pieces

TENDICATENA PER MOTOSEGHE CHAIN TIGHTNERS FOR CHAINSAWS

Art. 54.270.3036
 Tendicatena adattabile a
 Chain tightner fits

HUSQVARNA 42

Filetto/Thread M5 x 55



10 pezzi/pieces

Art. 54.270.3035
 Tendicatena adattabile a
 Chain tightner fits

HUSQVARNA

36 • 41 • 136 • 137 • 141 • 148 •



10 pezzi/pieces

Art. 54.270.3044
 Tendicatena adattabile a
 Chain tightner fits

OLEO MAC

945 • 950 • 950 SUPER



10 pezzi/pieces

Art. 54.270.3041
 TENDICATENA adattabile a
 Chain tightner fits

OLEO MAC

233 • 234 • 240 • 244 • 335 • 340



10 pezzi/pieces

Art. 54.270.3042
 TENDICATENA adattabile a
 Chain tightner fits

OLEO MAC

251 • 254 • 264 • 350 • 355
 E300 (1° tipo / first type)



10 pezzi/pieces

Art. 54.270.3046
 TENDICATENA adattabile a
 Chain tightner fits

OLEO MAC

260 • 261



10 pezzi/pieces

Art. 54.270.3007
 Tendicatena adattabile a
 Chain tightner fits

McCULLOCH

Mini-Mac 600



10 pezzi/pieces

Art. 54.270.3008
 Tendicatena
 adattabile a
 Chain
 tightner
 fits

McCULLOCH

100 • 300 •
 Mini-Mac 300



10 pezzi/pieces

Art. 54.270.3056
 TENDICATENA adattabile a
 Chain tightner fits

PARTNER

R16 • S50 • S55 • S65 • P70 •
 P100 • P55 • 550 • 650 • 700 •



10 pezzi/pieces

Art. 54.270.3035
 Tendicatena adattabile a
 Chain tightner fits

PARTNER

CCS 35•CCS 370•CCS 390•CCS420

POULAN

1625 • 1800 • 2000 • 2050 • 2550 • 2900



10 pezzi/pieces

Art. 54.270.3047
 Tendicatena adattabile a
 Chain tightner fits

POULAN

MICRO 25 • DELUXE 250



10 pezzi/pieces

Art. 54.270.3061
 TENDICATENA adattabile a
 Chain tightner fits

STIHL

028 • 038 •



10 pezzi/pieces

Art. 54.270.3051
 TENDICATENA adattabile a
 Chain tightner fits

STIHL

029 • MS290 • 039 • MS390



10 pezzi/pieces

Art. 54.270.3053
 TENDICATENA adattabile a
 Chain tightner fits

STIHL

• 021 • MS210 • 023 • MS230 • 025
 • MS250 •



10 pezzi/pieces

Art. 54.270.3062
 TENDICATENA adattabile a
 Chain tightner fits

STIHL

• 031 • 032 • 041 • 042 •
 • 045 • 048 • 056 (2° mod)



10 pezzi/pieces

Art. 54.270.3063
 TENDICATENA adattabile a
 Chain tightner fits

STIHL

08 • 050 • 051 • 070 • 075 • 090



10 pezzi/pieces

Art. 54.270.3064
 TENDICATENA adattabile a
 Chain tightner fits

STIHL

• 024 • 026 • 028 • 034 •
 • 044 • 064 • 084



10 pezzi/pieces

Art. 54.270.3048
 TENDICATENA adattabile a
 Chain tightner fits

ZENOAH

• 2500 •



10 pezzi/pieces

Art. 54.270.3049
 TENDICATENA adattabile a
 Chain tightner fits

ZENOAH

• 4500 •



10 pezzi/pieces

Art. 54.270.3050
 TENDICATENA adattabile a
 Chain tightner fits

ZENOAH

• 6200 •



10 pezzi/pieces